


AKKU-BOHRMASCHINE

HP122K----A

TYPE 1



AKKU-BOHRMASCHINE

HP122K----A TYPE 1



Pos. Nr	Ersatzteilnummer	Beschreibung	Preis	Variants
1	1	5100028-02	GEHAEUSEPAAR	
2	1	5100031-00	ANTRIEB	
3	1	148354-03	HALTER	
4	1	419581-01	KLINGE	
5	1	5100005-02	SCHALTER	
7	1	5100039-00	ANTRIEB	
8	6	311993-00	SCHRAUBE	
9	1	419233-00	SPANNBOHRFUTTER	
10	1	149518-01	SCHRAUBE	
11	1	5100040-00	DRAHT	
12	2	5100035-00	FEDER	
13	1	5100047-02	SCHILD	
14	1	419701-04	MOTOR	
15	1	419728-12	GETR.GEH.	
16	1	499948-03	ACCU-PACK	
17	1	5100235-04	LADEGERAET	GB
17	1	90501635	LADEGERAET (EURO)	QW
18	3	498511-00	SCHRAUBE	
20	1	5100032-02	GEHAEUSE	
21	1	5100003-02	GEHAEUSE	
23	1	5100017-00	SCHILD	
24	1	5100049-00	PLATTE	
25	2	5100060-00	SCHRAUBE	