


AKKU-BOHRMASCHINE

HP122K---B

TYPE 2



AKKU-BOHRMASCHINE

HP122K----B

TYPE 2



Pos. Nr	Ersatzteilnummer	Beschreibung	Preis	Variants
1	1	5100028-06	GEHAEUSE	
2	1	5100031-00	ANTRIEB	
3	1	148354-03	HALTER	
4	1	419581-01	KLINGE	
5	1	5100005-02	SCHALTER	
7	1	5100039-00	ANTRIEB	
8	6	497283-01	SCHRAUBE	
9	1	419233-09	SPANNBOHRFUTTER	
10	1	149518-01	SCHRAUBE	
11	1	5100040-00	DRAHT	
12	2	5100035-01	FEDER	
13	1	5100047-06	AUFKLEBER	
14	1	90503556	MOTOR + ZW.GETR.	
15	1	5100850-36	GETR.GEH.	
16	1	499948-30	BATTERIE	HP122K
16	2	499948-30	BATTERIE	HP122KB
17	1	90500869	LADEGERAET (EURO)	QW
17	1	90501636	LADEGERAET ZSB	GB
17	1	90501636	LADEGERAET ZSB	GB
18	3	498511-01	SCHRAUBE	
20	1	5100032-02	GEHAEUSE	
21	1	5100003-02	GEHAEUSE	
23	1	5100017-00	SCHILD	
24	1	5100049-00	PLATTE	
25	2	5100060-01	SCHRAUBE	