


# AKKU-BOHRMASCHINE

## HP188F2---A

## TYPE 1



©

# AKKU-BOHRMASCHINE

## HP188F2---A

## TYPE 1



Pos. Nr	Ersatzteilnummer	Beschreibung	Preis	Variants	
2	1	90500871	LADEGERAET (EURO)	QW	
2	1	90500874	LADEGERAT	GB	
2	1	000000-00	NICHT MEHR LIEFERBAR	QW	HP188FKH
4	3	311993-00	SCHRAUBE		
5	1	486562-00	SCHRAUBE		
6	2	498099-00	SCHRAUBE		
7	1	5101943-00	GETR.GEH.		UpTo DC 05-2003
7	1	5100850-38	GETR.GEH.		From DC 06-2003
8	1	5100111-00	ANTRIEB		
9	1	5102261-00	SCHALTER ZSB		
10	1	5100153-00	DRAHT		
11	1	5100101-02	ANTRIEB		UpTo DC 05-2003
11	1	5100101-03	ANTRIEB		From DC 06-2003
12	1	5101812-00	DECKEL		
14	1	5102271-00	GEHAEUSEPAAR		UpTo DC 05-2003
14	1	5101937-01	GEHAEUSEPAAR		From DC 06-2003
16	1	149518-01	SCHRAUBE		
17	1	419233-00	SPANNBOHRFUTTER		UpTo DC 05-2003
17	1	419233-09	SPANNBOHRFUTTER		From DC 06-2003
18	1	90506759	MOTOR + ZW.GETR.		
19	1	569036-00	AUFKLEBER		
20	1	5101893-00	TYPENSCHILD		
21	2	5100035-01	FEDER		
22	1	5101990-00	GRIFF ZSB		