




AKKU-BOHRMASCHINE HP96K-----A

TYPE 1



Pos. Nr	Ersatzteilnummer	Beschreibung	Preis	Variants
1	1	5100028-01	GEHAEUSEPAAR	
2	1	5100031-00	ANTRIEB	
3	1	148354-03	HALTER	
4	1	419581-01	KLINGE	
5	1	5100005-01	SCHALTER ZSB	
8	6	311993-00	SCHRAUBE	
9	1	419233-00	SPANNBOHRFUTTER	
10	1	149518-01	SCHRAUBE	
12	2	5100035-00	FEDER	
13	1	5100047-02	SCHILD	
14	1	497784-34	MOTOR ZSB9,6V	
15	1	5100096-00	GETR.GEH.	
16	1	5100294-04	ACCU-PACK 9.6V	
17	1	5101182-05	LADEGERAET ZSB	GB GB MARKET
17	1	5101182-00	LADEGERAET (EURO)	QW QW MARKET
18	3	498511-00	SCHRAUBE	
20	1	5100032-01	ABDECKUNG	
21	1	5100003-02	GEHAEUSE	
23	1	5100017-00	SCHILD	
24	1	5100049-00	PLATTE	
25	2	5100060-00	SCHRAUBE	
26	4	419471-00	SCHRAUBE	