




STICHSÄGE

KS635S----D

TYPE 4



Pos. Nr	Ersatzteilnummer	Beschreibung	Preis	Variants
1	1	576376-03	MOTOR ZSB	
2	1	580157-00	GEHAEUSE	
3	1	809483-04	SCHALTER	
4	1	807285-06	KONDENSATOR	
6	1	770235	SCHUTZ	
7	1	330080-03	KABELSATZ (EURO)	B1
7	1	330080-03	KABELSATZ (EURO)	QS
7	1	330080-06	KABELSATZ	XE
7	1	330060-53	KABELSATZ	GB
7	1	330060-53	KABELSATZ	XD
7	1	330080-05	KABELSATZ	CH
7	1	573379-01	KABEL	AR
8	1	369328	REGLER	
9	1	376010-01	ANTRIEB	
12	2	847709	FEDER	
13	2	372523	KOEHLE	
14	2	846076	KOEHLEKASTEN	
15	1	811504	LITZE	
16	1	811529	LITZE ZSB	
17	2	828446	DROSSEL ZSB	
18	1	369620	MUTTER	
19	1	581229-01	GETR.GEH.	
20	1	369619	GETRIEBE	
21	6	891024	SCHRAUBE	
22	1	368389	ROLLER	
23	2	368360	KUGELLAGER	
24	1	578308-01	WELLE ZSB	
25	3	374292	STIFT	
26	1	799310	O-RING	
29	2	570821-00	UNTERLEGSCHEIBE	
30	1	368366	ABDECKUNG	
31	1	369008	SCHUTZ	
32	1	370584	SCHUTZ	
33	1	580121-00	TYPENSCHILD	
34	1	368375-01	HALTERUNG ZSB	
35	1	368857-00	KLAMMER	
36	2	376409	SCHRAUBE	
37	1	369304-00	SCHUH ZSB	
44	1	581190-02	KLEMME ZSB	
45	10	747329	SCHRAUBE	
46	1	749286	BUEGEL	
47	1	368355-03	KRAGEN	
48	1	368363	BLOCK	
49	1	368352-00	OBERER KNOPF	
50	1	371662	FEDER	
51	1	368353-00	UNTERER KNOPF	
52	1	371311	PLATTE	
53	1	811057	STIFT	
54	2	812171	SCHRAUBE	