




TYPE

KS634S

STICHSÄGE

KS638SE---A

TYPE

1



17	2	828446	DROSSEL ZSB	
17	2	828446	DROSSEL ZSB	
17	2	828446	DROSSEL ZSB	
17	2	828446	DROSSEL ZSB	
17	2	828446	DROSSEL ZSB	
17	2	828446	DROSSEL ZSB	
17	2	828446	DROSSEL ZSB	
17	2	828446	DROSSEL ZSB	
17	2	828446	DROSSEL ZSB	
17	2	828446	DROSSEL ZSB	
17	2	828446	DROSSEL ZSB	
17	2	828446	DROSSEL ZSB	
17	2	828446	DROSSEL ZSB	
17	2	828446	DROSSEL ZSB	XE
18	1	369620	MUTTER	
19	1	581229-01	GETR.GEH.	
20	1	369619	GETRIEBE	
21	6	891024	SCHRAUBE	
22	1	368389	ROLLER	
23	2	368360	LAGER	
24	1	571709-04	WELLE ZSB	
25	3	374292	STIFT	
26	1	799310	O-RING	
27	1	371953	FEDER RECHTS	
28	1	371952	FEDER LINKS	
29	2	995036	FEDERSCHEIBE	
30	1	368366	ABDECKUNG	
31	1	369008	SCHUTZ	
32	1	370584	SCHUTZ	
33	1	369002-08	TYPENSCHILD	KS634S
33	1	369002-09	TYPENSCHILD	KS635S
33	1	369002-10	TYPENSCHILD	KS635S XE
ONLY				
33	1	369002-11	TYPENSCHILD	KS638SE
34	1	368375-00	HALTERUNG ZSB	
35	1	368857-00	KLAMMER	
36	2	376409	SCHRAUBE	
37	1	369304-00	SCHUH ZSB	
39	1	580571-00	KLAMMER	
40	1	370169	PLATTE	
41	2	370170	SPRENGRING	
42	1	571131-00	TEILEPAKET (SATZ)	
43	1	370168-01	ANTRIEB	
44	1	581190-02	KLEMME ZSB	
45	10	747329	SCHRAUBE	
46	1	749286	BUEGEL	
47	1	368355-00	KRAGEN	
48	1	376132	BLOCK	
49	1	368352-00	OBERER KNOPF	
50	1	371662	FEDER	
51	1	368353-00	UNTERER KNOPF	
52	1	371311	PLATTE	
53	1	811057	STIFT	