


800



©

STICHSÄGE

KS710LK---A

TYPE

1



Pos. Nr	Ersatzteilnummer	Beschreibung	Preis	Variants
1	1	597334-00	GEHAEUSE RECHTS	
2	1	597335-00	GEHAEUSE LINKS	
3	1	597336-00	KUGELLAGER	
4	1	597337-00	FELD 230V	
5	1	597338-00	ANKER 230V	
6	2	597339-00	KOHLE	
7	2	597340-00	KOHLEHALTER	
8	1	597341-00	KUGELLAGER	
9	1	597342-00	GETR.GEH.	
10	1	597343-00	STIFT	
11	2	597344-00	STIFT	
12	1	597345-00	UNTERLEGSCHEIBE	
13	1	597346-00	PLATTE	
14	2	597347-00	FLIEHGEWICHT	
15	1	597348-00	UNTERLEGSCHEIBE	
16	1	597349-00	GETRIEBE	
17	1	597350-00	UNTERLEGSCHEIBE	
18	1	597351-00	RING	
19	1	597352-00	NADELLAGER	
20	2	597353-00	UNTERLEGSCHEIBE	
21	2	597354-00	RING	
22	1	597355-00	WELLE ZSB	
24	1	597356-00	GLEITLAGER	
25	1	597357-00	SCHRAUBE	
26	1	597358-00	KLAMMER	
27	4	597359-00	FEDER	
28	1	597360-00	HALTER	
29	1	597361-00	SCHALTER	
30	1	597362-00	ELEKTRONIK	
31	2	597363-00	SCHRAUBE	
32	1	597364-00	KABELKLEMME	
33	1	597365-00	DREHACHSE	
34	1	597366-00	FEDER	
35	1	597367-00	HEBEL	
36	2	AAABATTERY	BATTERIE	
37	1	597368-00	ZSB GEHAEUSE	
38	1	597369-00	HALTERUNG	
39	1	597370-00	ACHSE	
40	1	597371-00	ACHSE	
41	1	597372-00	STIFT	
42	1	597373-00	MUTTER	
43	1	597374-00	MESSERHALTERUNG ZSB	
44	1	597375-00	BODENPLATTE	
45	1	597376-00	ABDECKUNG	
46	1	597377-00	HALTER	
47	6	597378-00	SCHRAUBE	
48	1	597379-00	SCHRAUBE	
49	1	597380-00	SCHUTZ	
50	1	597381-00	SCHRAUBE	
51	1	597382-00	VAKUUMADAPTER	
52	1	597383-00	TYPENSCHILD	
53	1	597384-00	TYPENSCHILD	
54	1	597385-00	KABELTUELLE	
55	1	597386-00	IMBUSSCHL. 3 MM	
56	1	597387-00	KABELSATZ (EURO)	DE
56	1	597387-00	KABELSATZ (EURO)	QS
56	1	597388-00	KABELSATZ	GB
57	2	597389-00	WELLE ZSB	

STICHSÄGE

KS710LK---A

TYPE

1



58	2	597390-00	BLOCK
59	4	597391-00	ROLLER
60	1	597392-00	GRIFFBEDECKUNG
61	2	1002479-00	FLÜGELSCHRAUBE
62	1	1002480-00	ANSCHLAG-BAUGRUPPE
800	1	870889-03	FETT