


STICHSÄGE KS850S----A TYPE 1



STICHSÄGE

KS850S----A

TYPE 1



Pos. Nr	Ersatzteilnummer	Beschreibung	Preis	Variants
1	1	90514628	KABELTUELLE	
2	1	90523264	KABELSATZ	GB
2	1	90530101	KABELSATZ (EURO)	XK
2	1	90530101	KABELSATZ (EURO)	QS
3	2	370748	SCHRAUBE	
4	1	329301-00	KABELKLEMME	
5	1	90525754	FELD 230V	GB
5	1	90525754	FELD 230V	XK
5	1	90525754	FELD 230V	QS
6	2	90510508	KOHLEKASTEN ZSB	
7	1	90513113	ANKER ZSB	GB
7	1	90513113	ANKER ZSB	XK
7	1	90513113	ANKER ZSB	QS
8	1	90525755	UNTERLEGSCHEIBE	
9	2	330019-17	SCHRAUBE	
10	1	90525756	LAGER PLATTEN	
11	1	90525758	GABEL	
12	1	90525759	FLIEHGEWICHT	
13	4	90517281	STIFT	
14	1	90526098	KUGELLAGER	
15	1	90526099	GETRIEBE	
16	1	90526100	UNTERLEGSCHEIBE	
17	1	90526101	KLIP	
18	1	823954	UNTERLEGSCHEIBE	
19	1	795688-00	ROLLER	
20	2	810893	KUGELLAGER	
21	1	90514115	STOESSEL	
22	1	582949-00	FILZDICHTUNG	
23	1	582948-00	PLATTE	
24	1	582593-00	MESSERKLEMME	
25	2	583173-00	SCHRAUBE	
26	1	90501915	VAKUUMADAPTER	
27	1	90514273	ANZEIGER	
28	2	330019-31	SCHRAUBE	
29	1	90514276	GRIFF	
30	1	620271-00	FEDER	
31	1	90517427	HEBEL ZSB	
32	1	90515286	BLOCK	
33	9	330019-13	SCHRAUBE	
34	1	90521038	ABDECKUNG	
35	1	90514228	EINSATZ	
36	1	90521037	SCHUH	
37	1	90513772	HALTER	
38	1	90514219	BOLZEN	
39	1	90514216	UNTERLEGSCHEIBE	
40	1	582827-00	BOLZEN	
41	1	90517413	ANTRIEB	
42	1	585385-00	SCHALTER ZSB	
43	1	90518917	PCB 230V	
44	1	90525568	HALTERUNG	
45	1	90514375	KAMM	
46	1	90521041	STIFT	
47	1	90521039	HALTER	
48	1	90514422	ROLLER	
49	1	90514409	STIFT	
50	1	587375-00	FESTSTELLRING	
51	1	330019-00	SCHRAUBE	
52	1	90521033	GEHAEUSEPAAR	

STICHSÄGE KS850S----A TYPE 1

				
53	1	326467-00	SPERRKLINKE	
54	1	90514622	KNOPF	
56	1	90520273	AUFKLEBER	
57	1	90521533	TYPENSCHILD	
58	1	90523047	SCHILD	
59	1	90523049	SCHILD	
60	1	90520107	SCHILD	
61	1	90514324	SCHAUM	
68	1	588384-00	ADAPTER ZSB	GB