




STICHSÄGE

KS900SL---A

TYPE

1



Pos. Nr	Ersatzteilnummer	Beschreibung	Preis	Variants
5	1	90514323 HALTERUNG		
6	1	90518917 PCB 230V		
7	1	585385-00 SCHALTER ZSB		
8	1	90517413 ANTRIEB		
9	1	90514375 KAMM		
10	1	90517396 KLEMME ZSB		
11	1	823954 UNTERLEGSCHEIBE		
12	1	795688 ROLLER		
13	1	90517366 GETRIEBE ZSB		
14	2	90516114 AUSGLEICHGEWICHT		
15	1	90516213 GABEL		
16	1	90514354 PLATTE DRUCK		
17	1	90514424 STIFT		
18	1	90517418 ROLLER ZSB		
19	1	90514324 SCHAUM		
20	1	90517308 FELD 230V		
21	1	90523334 ANKER ZSB		
22	2	90521673 KOHLE + FEDER		
23	2	582696-00 KOHLEKASTEN		
24	1	90517433 SCHUH ZSB		
25	1	90513772 HALTER		
26	1	90514216 UNTERLEGSCHEIBE		
27	1	90514219 BOLZEN		
28	1	582827-00 BOLZEN		
29	2	330019-00 SCHRAUBE		
30	1	90514228 EINSATZ		
31	1	90521871 FEDER		
32	1	90515286 BLOCK		
33	1	90514276 GRIFF		
34	1	90517427 HEBEL ZSB		
35	1	90501915 VAKUUMADAPTER		
36	1	90514628 KABELTUELLE		
37	1	90523264 KABELSATZ		GB
37	1	90518781 KABELSATZ (EURO)		QS
38	1	329301-00 KABELKLEMME		
39	2	370748 SCHRAUBE		
40	1	90514622 KNOPF		
41	1	326467-00 SPERRKLINKE		
42	1	330045-02 SCHRAUBE		
43	2	330019-17 SCHRAUBE		
44	9	330019-13 SCHRAUBE		
45	3	330045-01 SCHRAUBE		
46	2	330019-00 SCHRAUBE		
47	1	90521166 AUFKLEBER		
48	1	90514273 ANZEIGER		
49	1	90520107 SCHILD		
50	1	90520273 AUFKLEBER		
51	1	90521533 TYPENSCHILD		
52	1	90521787 SCHILD		
53	1	90521788 SCHILD		
56	1	489246-00 EINSATZ		
58	1	489427-00 SCHRAUBE		