



This diagram is an exploded view of a mechanical assembly, likely a portable electronic device or a small engine component. It shows various parts numbered 1 through 100, arranged in a way that illustrates their relative positions and how they fit together. The components include a main housing (1), internal circuitry or components (2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56), a motor or actuator (57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100), and various fasteners like screws, bolts, and washers. The diagram is a technical drawing with clear lines and numbers, typical of a service manual.



94575

Pos.-Nr.	Ersatzteil-Nr.	Bezeichnung <u>Abb.1</u>	Pos.-Nr.	Ersatzteil-Nr.	Bezeichnung <u>Abb.1</u>
001	94575-01001	Auswurfschacht	031	94575-01031	Bremsplatte rechts
002	94575-01002	Schutz Auswurfschacht	032	94575-01032	Reiblager kpl.
003	94575-01003	Gleitkufe	033	94575-01033	Lager
004	94575-01004	Halterung Auswurfschacht kpl.	034	94575-01034	Abdeckung Umlenkrolle
005	94575-01005	Schneckengetriebe kpl.	035	94575-01035	Holm vvl.
006	94575-01006	Schaufelrad	036	94575-01036	Holm vvr.
007	94575-01007	Schnecke vvr.	037	94575-01037	Kupplungszug
008	94575-01008	Schnecke vvl.	038	94575-01038	Zug Schnecke
009	94575-01009	Abscherbolzen kpl.	039	94575-01039	Hebel
010	94575-01010	Schneide unten	040	94575-01040	Handgriffhülse/ Beheizt
011	94575-01011	Schneckenrad	041	94575-01041	Lenkhebel vvl.
012	94575-01012	Befestigungsplatte Schneckenrad	042	94575-01042	Lenkhebel vvr.
013	94575-01013	Rutschalthebel	043	94575-01043	Schalter
014	94575-01014	Gelenk	044	94575-01044	Lampe
015	94575-01015	Sicherungssplint	045	94575-01045	Hebel Höhenverstellung
016	94575-01016	Kurbel	046	94575-01046	Zug Vorwärtsgang
017	94575-01017	Antriebsachse	047	94575-01047	Zug Rückwärtsgang
018	94575-01018	Abdeckung Antrieb	048	94575-01048	Hebel Auswurfschacht
019	94575-01019	Lager Schaufelrad kpl.	049	94575-01049	Zug Auswurfschacht
020	94575-01020	Umlenkrolle Schnecke	050	94575-01050	Rad
021	94575-01021	Hebel Schaltung	051	94575-01051	Kette
022	94575-01022	Feder Druckplatte	056	94575-01056	Lagergehäuse kpl.
023	94575-01023	Druckplatte	086	94575-01086	Feder Schnecke unten
024	94575-01024	Lager Druckplatte kpl.	097	94575-01097	Holm
025	94575-01025	Druckscheibe	098	94575-01098	Gashebel
026	94575-01026	Lager	099	94575-01099	Zug Auswurfschacht
027	94575-01027	Sechskantwelle	100	94575-01100	Rückholfeder
028	94575-01028	Reibrad	o.Abb.	94575-01102	Riemen
029	94575-01029	Bremsplatte links	o.Abb.	94575-01103	Zahnriemen
030	94575-01030	Reibscheibe	o.Abb.	94575-01105	Riemenscheibe Motor
			o.Abb.	94575-01106	Zug Lenkhebel
			o.Abb.	94575-01107	Kette Antrieb lang
			o.Abb.	94575-01108	Kette Antrieb kurz

Abb.2





Abb.3





94575

Pos.- Nr.	Ersatzteil-Nr.	Bezeichnung <u>Abb.3</u>	Pos.- Nr.	Ersatzteil-Nr.	Bezeichnung <u>Abb.4</u>
052	94575-01052	Entlüftungsschlauch	063	94575-01063	Ölmessstab
053	94575-01053	Regler groß	064	94575-01064	Deckel Kurbelgehäuse
054	94575-01054	Reglerarm	065	94575-01065	Ölstopfen
055	94575-01055	Ölsensor	066	94575-01066	Lager Kurbelwelle kpl.
057	94575-01057	Kurbelgehäuse	068	94575-01068	Fliehkraftregler
058	94575-01058	Ölablassschraube	069	94575-01069	Welle Drehzahlregler
059	94575-01059	Ventildeckel	070	94575-01070	Kurbelwelle
060	94575-01060	Dichtungssatz Motor	072	94575-01072	Kolbenringe
061	94574-01073	Zündkerze LG F 7TC	073	94575-01073	Kolben kpl.
062	94575-01062	Zylinderkopf	074	94575-01074	Pleuel
			075	94575-01075	Kolbenbolzen

Abb.4







Abb.5






94575

Pos.- Nr.	Ersatzteil-Nr.	Bezeichnung <u>Abb.4</u>	Pos.- Nr.	Ersatzteil-Nr.	Bezeichnung <u>Abb.5</u>
076	94575-01076	Ventilsatz kpl.	080	94575-01080	Entstördrossel
077	94575-01077	Anwerfe	081	94575-01081	Zündspule
079	94575-01079	Vergaser	082	94575-01082	Poolrad
			083	94575-01083	Lüfterrad
			084	94575-01084	Drehzahlregler
			085	94575-01085	Luftfilter
			086	94575-01086	Abdeckung Vergaser
			087	94575-01087	Luftfiltereinsatz
			104	94575-01104	Mitnehmerbüchse

Abb.6





94575

Pos.- Nr.	Ersatzteil-Nr.	Bezeichnung <u>Abb.6</u>	Pos.- Nr.	Ersatzteil-Nr.	Bezeichnung <u>Abb.6</u>
088	94575-01088	Abdeckung Auspuff	093	94575-01093	Kraftstoffschlauch kpl.
089	94575-01089	Auspuff	094	94575-01094	Zündanlage
090	94575-01090	Kraftstofftank	095	94575-01095	Überlastschalter
091	94575-01091	Deckel Kraftstofftank	096	94575-01096	Zündschloss
092	94575-01092	Filter			