

ICT16A

Spare parts

Ersatzteile

Pièces détachées


Reserve onderdelen

Repuestos

Reservdelar

REPAIR PARTS

TRACTOR- -MODEL NO. ICT16A (JICTH16G) PRODUCT NO. 954 13 00-42
ELECTRICAL



REPAIR PARTS

TRACTOR- -MODEL NO. ICT16A (JICTH16G) PRODUCT NO. 954 13 00-42
ELECTRICAL

KEY NO.	PART NO.	DESCRIPTION
1	532144925	Battery 12 Volt 25 AMP Wet
2	874760412	Bolt Hex Hd 1/4-20 Unc X 3/4
16	532153664	Switch Interlock Push-In
21	532166182	Harness Asm Light W/4152J
22	532004152	Bulb Light #1156
24	532124780	Cable Starter 6Ga 11" Red
25	532165987	Cable Battery Crd 56" Red
26	532175158	Fuse
27	873510400	Nut Keps Hex 1/4-20 Unc
28	532127725	Cable Ground 6Ga 18" Black
29	532160784	Switch Plunger Normal Op Olive
30	532175566	Switch Ignition
33	532140401	Key Ign Molded
40	532170214	Harness Ign Crd Elect
41	871110408	Bolt Flk Fin Hex 1/4-20 Unc X 1/2
42	532131563	Cover Terminal Red
43	532175141	Solenoid
48	532140844	Adapter Ammeter Rectangular
50	532174651	Switch PTO 8
51	532140405	Ring Retainer PTO
52	532141940	Protection Wire Loop
58	532169419	Buzzer Crd
59	532166299	Switch FBI CRD
65	817211008	Screw Slftp #10-16 x 1/2 Ty-Ab
66	817490608	Screw Thdrol 3/8-16 x 1/2 Ty-Tt
80	532146685	Harness Clutch EVX
81	532109748	Relay Asm

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm.

REPAIR PARTS

TRACTOR- -MODEL NO. ICT16A (JICTH16G) PRODUCT NO. 954 13 00-42
CHASSIS AND ENCLOSURES

REPAIR PARTS

TRACTOR- -MODEL NO. ICT16A (JICTH16G) PRODUCT NO. 954 13 00-42 CHASSIS AND ENCLOSURES


KEY NO.	PART NO.	DESCRIPTION
1	532169831	Chassis Stamping
2	532165606	Drawbar
3	817060612	Screw 3/8-16 x .75
5	532155272	Bumper Hood/Dash
6	532155923	Saddle
8	532126471	Clip Insulator 13/32 Mtg. Hole
9	532172099	Dash
10	872140608	Bolt, Carriage 3/8-16 x 3/4
11	532155927	Panel, Dash, L.H.
12	532145660	Clip Tinnerman Grille P/L
13	532172108	Panel, Asm. Dash R.H.
15	874180512	Screw, Machine, Truss Head 5/16-18 UNC x 3/4
16	873510500	Nut
17	532150760	Hood Assembly
18	532126938	Bumper Hood
20	532156437	Plate Mtg. Battery/Fuel Tank
24	874780616	Bolt
25	819131312	Washer 13/32 x 13/16 x 12 Gauge
26	873800600	Nut
28	532169509	Grille PL
29	532166603	Lens, Grille
30	532175843	Fender
31	532165156	Bracket, Fender Support
33	532149139	Footrest, L.H.
34	532149140	Footrest, R.H.
35	872110606	Bolt
37	817490508	Screw Thdrol 5/16-18 x 1/2 TYT
38	532169834	Bracket Asm Pivot Mower Rear
51	873800400	Nut Lock w/Insert 1/4-20 UNC
52	819091416	Washer 9/32 x 7/8 x 16 Ga.
53	532145201	Bracket Grille Pick off Lh
54	532161464	Screw Hex Ws Hd 8-18 x 7/8
55	532145202	Bracket Grille Pick off Rh
57	874780412	Bolt, Fin Hex 1/4-20 UNC x .75
71	873680400	Nut Crownlock 1/4-20 UNC
102	532124996	Clip Fuel Line 13/32 Mtg Hole

KEY NO.	PART NO.	DESCRIPTION
145	532156524	Rod Pivot Chassis/Hood
162	532170256	Bracket Exten Chassis Lh CRD
163	532175770	Bracket Exten Chassis Rh CRD
164	532165605	Support Battery CRD
165	532168407	Cover Battery CRD Lt
167	532165779	Support Asm. Backplate WLD MNT
168	872050412	Bolt, RDHD SHT NK 1/4-20 x 1-1/2
169	532123976	Nut, Lock 1/4 LGE FLG Gr. 5 Zinc
170	532175264	Backplate
171	874520640	Bolt Rdhd Sqnk 3/8-16 x 2-1/2 G 5
172	819132016	Washer 13/32 x 1-1/4 x 16 Ga.
173	873510600	Nut, Keps Hex 3/8-16 UNC
174	532165939	Bracket Switch FBI CRD
175	532166212	Guard Door Rear CRD
176	532128600	Pin Hinge Pivot
177	532132796	Spring Bagger Top LH Black
178	876020312	Pin Cotter 3/32 x 3/4 Cad Zinc
179	532165942	Rod Pivot FBI CRD
183	819131316	Washer 13/32 x 13/16 x 16 Ga.
184	532174662	Bracket Actuator Bagger CRD
185	532165940	Tube Lever Switch FBI CRD
186	532160793	Latch Asm Multch Bagger
187	532125004	Nut Weld .327/.304 #10-24
188	819061216	Washer #10
189	810071000	Washer Lock #10
190	871081010	Screw Pan Hd Phil 10-24 x 5/8
192	817060624	Screw Thdrol 3/8-16 x 1-1/2
193	817070412	Screw Truss 1/4-20 x 3/4
198	532168937	Nut, Push
207	817670508	Screw Thdrol 5/16-18 x 1/2
208	817670608	Screw Thdrol 3/8-16 x 1/2
209	817000612	Screw Hex Wsh Thdrol 3/8-16
212	532165919	Insert Lens Reflective
213	872110406	Carriage Bolt
--	532005479	Button Plug

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm.

REPAIR PARTS

TRACTOR- -MODEL NO. ICT16A (JICTH16G) PRODUCT NO. 954 13 00-42
DRIVE



REPAIR PARTS


TRACTOR- -MODEL NO. ICT16A (JICTH16G) PRODUCT NO. 954 13 00-42
DRIVE

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	-----	Transaxle Hydro Gear 321-0510 (Order parts from transaxle manufacturer)	78	532121748	Washer 25/32 x 1-5/8 x 16 Ga.
8	532165619	Rod, Shift Fender Adjust Lt	81	532170006	Asm, Shaft
9	532175540	Clutch Ele EVX	82	532123782	Spring, Torsion
10	876020416	Pin, Cotter 1/8 x 1	83	819171216	Washer 17/32 x 3/4 x 16 Ga.
14	810040400	Washer, Lock Hvy Helical	84	532170007	Link, Transaxle
15	874490544	Bolt Hex FLGHD 5/16-18 Gr. 5	95	532170015	Control Asm Bypass Hydro
16	873800500	Nut, Lock Hex w/Ins 5/16-18 UNC	96	532124788	Spring, Retainer 1"
17	532126197	Washer 1-1/2 OD x 15/32 ID x .250	120	873900600	Nut Lock Flg 3/8-16 UNC
19	873800600	Nut Lock Hex W/Ins 3/8-16	144	819111016	Washer 11/32 x 5/8 x 16 Ga.
21	532130564	Knob Deluxe 1/4-13 Unc Blk	150	532165850	Bushing, Bellcrank Grnd Dr
22	532170137	Rod, Brake	151	819133210	Washer 13/32 x 2 x 10 Ga.
23	532170017	Bracket asm Clutch Mtg.	153	874760512	Bolt Hex Hd 5/16-18 Unc x 3/4
24	873350600	Nut	156	532166002	Washer Srrtd 5/16ID x 1.125
25	532106888	Spring, Rod, Brake	158	532165589	Bracket Shift Mount
26	819131316	Washer 13/32 x 13/16 x 16 Ga.	159	532165494	Hub Tapered Flange Shift Lt
27	876020412	Pin, Cotter 1/8 x 3/4	160	819292016	Washer 29/32 x 1-1/4 x 16 Ga.
28	532145204	Rod, Parking Brake	161	872140406	Bolt Rdhd Sqnk 1/4-20 x 3/4 Gr 5
29	532071673	Cap, Parking Brake	162	873680400	Nut Crownlock 1/4-20 Unc
30	532169592	Bracket, Mfg. Transaxle	163	874780416	Bolt Hex Fin 1/4-20 Unc x 1 Gr 5
32	874760516	Bolt Hex 5/16-18 UNC x 1	164	819091010	Washer 5/8 x .281 x 10 Ga.
33	872140506	Bolt Rdhd Sqnk 5/16-18 Unc x 3/4	165	532165623	Bracket Pivot Lever
34	532165496	Shaft, Asm Pedal Foot CRD	166	532166880	Screw 5/16-18 x 5/8
35	532120183	Bearing, Nylon	167	532165588	Bracket Support Shift CRD
36	819211616	Washer 21/32 x 1 x 16 Ga.	168	532165492	Bolt Shoulder 5/16-18 x .561
37	532124963	Pin, Roll 3/16 x 1"	169	532165580	Plate Fastening Lt
38	532165936	Pulley Flat Composite 3.06"	171	817490608	Screw Thdrol 3/8-16 x 1/2 Ty-Tt
39	874760644	Bolt Fin Hex 3/8-16 Unc x 2-3/4	172	532170271	Shaft Asm Shifter Frt
40	532124965	Spacer, Split 395 x 59 Bzp	174	810090400	Washer Lock 1/4
42	819131312	Washer 13/32 x 13/16 x 12 Ga.	177	532165932	Keeper Flat Idler 3.06" CRD
47	532127783	Pulley, Idler, V Groove Plasic	178	532165933	Keeper Belt Idler 1.88" CRD
48	532154407	Bellcrank Clutch Grnd Drv	179	532120958	Washer Sintered
49	532123205	Retainer, Belt Style Spring	180	532165630	Pulley, Idler, Flat 1.88"CRD
50	874760624	Bolt Hex Hd 3/8-16 UNC x 1-1/2	181	532165797	Bracket Idler Ground Drive CRD
51	873680600	Nut, Crownlock 3/8-16 UNC	182	532165634	Keeper Belt 2.5" Od V-Idler CRD
52	873680500	Nut Crownlock 5/16-18	183	532165626	Pulley V-Idler 2.50" Od CRD
53	532105710	Link, Clutch 7.66	184	817490644	Screw Hexwsh Thdrol 3/8-16 x 2-3/4
55	532105709	Spring, Return, Clutch	185	532170008	Link Shift CRD Hydro
56	874760620	Bolt, Hex 3/8-16 UNC x 1-1/4	186	532165614	Hub Tapered Round CRD
57	532170140	V-Belt Kev 113"	187	817060620	Screw 3/8-16 x 1-1/4
61	817060612	Screw 3/8-16 x 3/4	188	532110436	Bushing Snap Split Blk
62	532124872	Cover, Pedal	197	532169613	Nyliner Snap-In 5/8" ID
63	532145868	Pulley, Clutch elect EVX 1"	199	532169612	Bolt Shoulder 5/16-18 UNC
65	810040700	Washer	200	872140508	Bolt RDHD SQNK 5/16-18unc x 1
66	532154778	Keeper, Belt Engine F-Proof	202	872110612	Bolt Carr. Sh. 3/8-16 x 1-1/2 Gr. 5
71	532169183	Strap, Torque, Lh	203	871170780	Bolt Hex 7/16-20 x 5
73	532169182	Strap, Torque, Rh	206	819131416	Washer 13/32 x 7/8 x 16 Ga.
74	532137057	Spacer	207	532169845	Washer Nylon Rear
75	532121749	Washer 25/32 x 1-1/4 x 16 Ga.	208	532169844	Bracket Idler Rear LH
76	812000001	Ring, E	209	872110606	Bolt RDHD SQNK 3/8-16 x 3/4
77	532123583	Key, Square			

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. ICT16A (JICTH16G) PRODUCT NO. 954 13 00-42
STEERING ASSEMBLY



REPAIR PARTS


TRACTOR- -MODEL NO. ICT16A (JICTH16G) PRODUCT NO. 954 13 00-42
STEERING ASSEMBLY

KEY NO.	PART NO.	DESCRIPTION
1	532172092	Steering Wheel
2	532172393	Axle Cast Lt Iron
3	532169840	Spindle Assembly, L.H.
4	532169839	Spindle Assembly, R.H.
5	532124931	Bearing, Race, Thrust, Hardened
6	532121748	Washer 25/32 x 1-5/8 x 16 Gauge
8	812000029	Ring, Klip
10	532169832	Link, Drag
11	810040600	Washer, Lock
13	532136518	Spacer Brg Axle Front
15	532145212	Nut Hex Flange Lock
17	532156546	Shaft Assembly, Steering
18	532057079	Washer, Thrust .515 x .750 x .033
19	532160395	Support, Shaft
22	532165857	Screw Hex Wshhd Torx
23	532165851	Pittman Shaft Assembly
25	532154406	Bracket, Steering
27	532136874	Gear, Sector
29	817060612	Screw 3/8-16 x 3/4
32	532170162	Rod, Tie
33	819111216	Washer 11/32 x 3/4 x 16 Ga.
34	810040500	Washer Lock Hvy Hlcl 5/16
35	873540500	Crownlock Nut 5/16-24
36	532155099	Bushing, Steering
37	532152927	Screw TT #10-32 x 5 x 3/8 Flange
38	532172093	Cap Wheel Steering
39	819132411	Washer 13/32 x 1-1/20 x 11 Gauge
40	532124701	Nut Lock Center 3/8-24 Unf
41	532159945	Adaptor, Steering Wheel
42	532169633	Boot, Steering
43	532121749	Washer 25/32 x 1-1/4 x 16 Gauge
44	532153720	Extension Steering Non-Adjust
46	532121232	Cap, Spindle
51	873800500	Nut Lock Hx W/Ins 5/16-18 UNC
54	874780520	Bolt Fin Hex 5/16-18 UNC x 1-1/4
62	532167902	Kit, Steering Assembly, Service
63	874780616	Bolt Fin Hex 3/8-16 unc. x 1 Gr. 5
65	532160367	Spacer Brace Axle
66	532154404	Bearing Arm Pittman
67	872140618	Bolt Rdhd Sqnk 3/8-16 x 2-1/4
68	532169827	Brace Axle
79	819132012	Washer 13/32 x 1-1/4 x 12 Ga
80	874950612	Bolt Hex Nylon 3/8-16 x 3/4
82	532169835	Bracket Susp Chassis Front
87	532173966	Washer Flat .781 x 1-1/2 x .14

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm.

REPAIR PARTS

TRACTOR- -MODEL NO. ICT16A (JICTH16G) PRODUCT NO. 954 13 00-42
SEAT ASSEMBLY




KEY NO.	PART NO.	DESCRIPTION
1	532140118	Seat
2	532140551	Bracket Pnt Pivot Seat (blk)
5	532145006	Clip Push In Hinged
7	532124181	Spring Seat Cprsn 2 250 Blk Zi
8	817000616	Screw 3/8-16 X 1
9	819131614	Washer 13/32 X 1 X 14 Ga
10	532174894	Pan Pnt Seat (blk)
11	532166369	Knob Seat Adj. Wingnut
12	532121246	Bracket Pnt Mounting Switch

KEY NO.	PART NO.	DESCRIPTION
13	532121248	Bushing Snap Blk Nyl 50 Id
14	872050412	Bolt Rdhd Sht Nk 1/4-20x1-1/2
15	532121249	Spacer Split 28 X 88 Zinc
16	532123740	Spring Cprsn
17	532123976	Nut Lock 1/4 Lge Flg Gr 5 Zinc
21	532171852	Bolt Shoulder 5/16-18 Unc-2A
22	873800500	Nut Hex Lock w/Ins 5/16-18
24	819171912	Washer 17/32 X 1-3/16 X 12 Ga.
25	532127018	Bolt Shoulder 5/16-18 X 62

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm

REPAIR PARTS


TRACTOR- -MODEL NO. ICT16A (JICTH16G) PRODUCT NO. 954 13 00-42
DECALS



KEY NO.	PART NO.	DESCRIPTION
1	532145498	Decal Read Owner's Manual Sym
2	532176400	Decal Hp Engine
3	532170533	Decal Hood Rh
4	532170534	Decal Hood Lh
6	532126187	Decal 100 DBA
7	532162927	Decal Hood Insert
8	532145437	Decal Europe Stand Ce
9	532141761	Decal Fender Logo
10	532145005	Decal Bat Dan/Poi P/L Sym Wpn
11	532145494	Decal Mower Cut Finger Symbol
12	532159737	Decal Brake/Clutch Symbol Lt
13	532166959	Decal Warn Back Plate CRD
14	532159736	Decal Chassis Hot Muffler

KEY NO.	PART NO.	DESCRIPTION
15	532166961	Decal Oper Bag Presence CRD
16	532162598	Decal Drawbar Load Limit
17	532140837	Decal Saddle Brake Parking
18	532152262	Decal Grille
20	532166960	Decal Bypass Fender CRD
21	532166286	Decal Hex Belt Sch 92 CRD
22	532170565	Decal Ins Strg Whl
23	532170654	Decal Bagger Top CRD
—	532138311	Decal Lift Handle
—	532171237	Pad Footrest
—	532175675	Manual Operator's (Euro)
—	532175676	Manual Operator's (Scan)

WHEELS & TIRES




KEY NO.	PART NO.	DESCRIPTION
1	532059192	Cap Value Tire
2	532065139	Stem Valve
3	532106222	Tire F Ts 15 X 6 0 - 6 Service
4	532059904	Tube Inner Front #35060
5	532138336	Rim Asm 6"front Silver Service
6	532124957	Fitting Grease
7	532124959	Bearing Flange
8	532138337	Rim Asm 8"rear Silver Service
9	532138468	Tire R Ts 20 x 8-8 Service
10	532124926	Tube Rear 9 5 X 8 Service
11	532175039	Cap Axle Blk 1 50 X 1 00
--	144334	Sealant, Tire (10 oz. tube)

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. ICT16A (JICTH16G) PRODUCT NO. 954 13 00-42
ENGINE



REPAIR PARTS


TRACTOR- -MODEL NO. ICT16A (JICTH16G) PRODUCT NO. 954 13 00-42
ENGINE

KEY NO.	PART NO.	DESCRIPTION
1	532170865	Control Throt/Ch
2	817720410	Screw Hex Thd Cut 1/4-20x5/8 T
3	-----	Engine B&S Model 311777 (Order parts from engine manufacturer)
4	532137352	Muffler Exh Lt
13	532165291	Gasket Muffler
14	532148456	Tube Drain Oil Easy
16	811050600	Washer Lock Ext Tooth 3/8
23	532169837	Shield Brn/Dbr Guard
29	532137180	Kit Spark Arrestor (Flat Scrn)
31	532174642	Tank Fuel 2.00
32	532140527	Cap Asm Fuel W/sym Vented
33	532123487	Clamp Hose Blk
37	532137040	Line Fuel
38	532148315	Plug Drain Oil Easy
44	817670412	Screw Hexwsh Thdrol 1/4-20 x 3/4
45	817000612	Screw Hexwsh Thdr. 3/8-16 x 3/4
46	819091416	Washer 9/32 x 7/8 x 16 Ga.
62	810040500	Washer, Lock Hvy. Hlcl Spr 5/16
66	532127951	Stop Throttle 3000 RPM
72	871070512	Screw Hex Hd Cap 5/16-18 x 3/4
78	817060620	Screw 3/8-16 x 1-1/4
81	873510400	Nut Heps Hex 1/4-20

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. ICT16A (JICTH16G) PRODUCT NO. 954 13 00-42
MOWER LIFT



REPAIR PARTS


TRACTOR- -MODEL NO. ICT16A (JICTH16G) PRODUCT NO. 954 13 00-42
MOWER LIFT

KEY NO.	PART NO.	DESCRIPTION
1	532159460	Washer Asm Inner Spring W/Plunger
2	532159471	Shaft Asm. Lift
3	532105767	Pin Groove
4	812000002	E Ring #5133-62
5	819211621	Washer 21/32 x 1 x 21 Ga.
6	532120183	Bearing Nylong
7	532125631	Grip Handle Fluted
8	532124526	Button Plunger Black
11	532165829	Link Asm Lift L.H.
12	532165831	Link Asm Lift R.H.
13	532124670	Retainer Spring
15	532173288	Link Front
16	873350800	Nut Jam Hex 1/2-13 Unc
17	532130171	Trunnion Blk Zinc
18	873800800	Nut Lock w/Wsh 1/2-13 Unc
19	532139868	Arm Suspension Mower
20	532163552	Retainer Spring
23	532110807	Nut Special
24	819131016	Washer 13/32 x 5/8 x 16 Ga.
25	532124874	Spring 2-1/8"
26	532169484	Retainer Clip
27	532126971	Rod Adj Lift Zinc 7.49 Wrk Lg
28	873350600	Nut Hex Jam 3/8-16 Unc
29	532138057	Knob Inf 3/8-16 Unc Blk w/sym
30	532150233	Trunnion Infin Height
31	532169865	Bearing, Pvt. Lift.
32	873540600	Nut Crownlock 3/8-24
36	532155097	Pointer Height Indicator
37	532123935	Plug Hole Blk 1.485/1.515 Dia
38	817060516	Screw 5/16-18 x 1
40	819112410	Washer 11/32 x 1-1/2 x 10 Ga.
41	532123934	Scale Ind Height Blk
49	532145212	Nut hex Flange Lock
50	532110452	Nut Push Phos & Oil

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. ICT16A (JICTH16G) PRODUCT NO. 954 13 00-42
MOWER



REPAIR PARTS

TRACTOR- -MODEL NO. ICT16A (JICTH16G) PRODUCT NO. 954 13 00-42
MOWER


KEY NO.	PART NO.	DESCRIPTION
1	532169160	Housing Asm. Mower
2	872140506	Bolt Rdhd Sqnk 5/16-18 Unc x 3/4
3	532165569	Bracket Asm. S-Bar Chass
4	532169167	Bracket Bar Sway Deck
5	532124670	Retainer Spring
6	532165557	Bar Sway
8	532850857	Bolt 3/8-24 x 1.25 Gr8 Patched
9	810030600	Washer Lock Hvy 3/8 Unplated
10	532140296	Washer Hard Blade Mower vented
11	532175450	Blade 3-1 Lh
13	532137645	Shaft Asm. W/Lower Bearing
14	532128774	Housing Mandrel Vented (Machd)
15	532110485	Bearing Ball Mandrel
16	532175451	Blade 3-1 Rh
17	872140610	Bolt Carr 3/8-16 x 1-1/4
19	532132827	Bolt Shoulder 5/16-18 Thd Form
20	532165484	Bolt 3/8-24 x 1.25 Gr8 Ptch Lhthd
21	873680500	Nut Crown Lock 5/16-18
22	532169165	Bracket Idler RR
23	532169166	Bracket Idler RF
24	532169170	Bracket Suspension LF
25	532169171	Bracket Suspension RF
26	532165237	Brace Support Susp Frt CRD
27	532169172	Bracket Asm. Susp RR
28	532169168	Bracket Asm. Susp LR
30	532157722	Screw Thd Rolling Washer Head
31	532129963	Washer Spacer Mower Vented
32	532175707	Mandrel Pulleys
33	532137266	Nut Flg Top Lock Cntr B 9/16

KEY NO.	PART NO.	DESCRIPTION
34	532176291	Bracket Gauge Wheel Lf
35	532176292	Bracket Gauge Wheel Rf
36	532146763	Pulley Idler V-Groove Dim 4.25
37	819131316	Washer 11/32 x 13/16 x 16 Ga
38	532169851	Spacer Hub Arm Idler 107 CRD
39	872110622	Bolt Rdhd 3/8-16 Unc x 2-3/4 Gr. 5
40	873680600	Nut Crownlock 3/8-16 Unc
41	873900600	Nut Lock Flg 3/8-16
44	532169180	Cover Mandrel Lh
45	532169179	Cover Mandrel Rh
46	532137729	Screw Thd Roll 1/4-20 x 5/8
55	532169849	Arm Idler 107 CRD
61	532175159	Spring Tension Belt
68	532169178	Hex-Belt Mower
69	532165482	Shaft Asm W/Lwr Brg Rh Thd CRD
84	532156085	Keeper Belt Idler
116	532137644	Bolt Shoulder
117	532133957	Wheel Gage Donut Wide
118	873930600	Nut Centerlock 3/8-16 Unc
119	819121414	Washer 3/8 x 7/8 x 14 Ga.
124	872110612	Bolt Carr Sh 3/8-16 x 1-1/2 Gr5
130	872110506	Bolt Rdhdsqnk 5/16-18 Unc x 3/4
131	532165661	Chute Bagger CRD 92cm
160	532175160	Guide Belt Crd
-	532130794	Mandrel Asm Service
-	532165579	Mandrel Asm CRD Lh Threads SVC
-	532175842	Deck Mower Complete

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. ICT16A (JICTH16G) PRODUCT NO. 954 13 00-42
BAGGER





REPAIR PARTS

TRACTOR- -MODEL NO. ICT16A (JICTH16G) PRODUCT NO. 954 13 00-42
BAGGER

KEY NO.	PART NO.	DESCRIPTION
1	532170690	Tube Handle Bagger CRD
2	872140416	Bolt Carriage 1/4-20 X 2.0 Gr.5
3	532123976	Nut Lock 1/4 Lge Flg Gr. 5 Zinc
4	532169916	Handle Bagger w/Lvrs Gr. 5 Zinc
5	874981024	Screw Pan Head #10-24 X 1.50 Blk
6	874981032	Screw Pan Hd
7	873401000	Nut Wiz Lock Hex Serr/Hd #10-24
8	532168871	Cover Bagger Plastic CRD
9	872140418	Bolt Carriage 1/4-20 x 2.25d x Gr.5
10	532169688	Tube Support Bagger CRD
11	532165719	Bracket Support Upper Bag CRD
12	532169685	Bracket Horiz. Adj Bagger
13	872110606	Bolt Rdhd Sht Sqnk 3/8-16 X 3/4
14	874520640	Bolt Hex 3/8-16 X 2-1/2 Gr. 5
15	532124670	Retainer Spring
16	873900600	Nut Lock Flg 3/8-16 Unc
17	872140506	Bolt Rdhd Sht Sqnk 5/16-18Unc X 3/4
18	819111216	Washer 11/32 x 3/4 x 16
19	873900500	Nut Lock Hex Flange 5/16-18 Unc Pl
20	532169684	Bracket Horiz Adj Bagger
21	532165780	Bag Asm CRD
22	532165781	Bracket Side Bagger CRD
23	532165782	Tube Upper Bagger CRD
24	532165783	Tube Pivot Bagger CRD
25	532165784	Tube Front Bagger CRD
26	532165785	Tube Lower Bagger CRD
27	532169692	Bushing Snap Bagger CRD
28	532170696	Grip Handle Black
31	532124788	Retainer Spring 1" Zinc/Cad
32	532126875	Rivet Rd Hd Drilled 3/8 Dia
33	532169380	Plug Mulch 107 CRD
34	532165570	Handle Mulcher 92/107 CRD
35	532165572	Pin Mulcher 92/107 CRD
36	819132016	Washer 13/32 x 1-1/4 x 16 Ga.
37	532175401	Plug Support
38	872010520	Bolt 5/16-18 x 2-1/2
39	532169999	Seal 26" (Long)
40	532170000	Seal 7" (Short)
41	532169683	Bracket Vert Adj Bagger CRD
42	873800500	Nut Lock Hx W/Ins 5/16-18

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm


TRACTOR- -MODEL NO. ICT16A (JICTH16G) PRODUCT NO. 954 13 00-42
SCHEMATIC




IGNITION SWITCH

POSITION	CIRCUIT	"MAKE"
OFF	M+G+A1	NONE
RUN/LIGHT	B+A1	A2+L
RUN	B+A1	NONE
START	B + S + A1	NONE

WIRING INSULATED CLIPS
NOTE: IF WIRING INSULATED CLIPS WERE REMOVED FOR SERVICING OF UNIT, THEY SHOULD BE REPLACED TO PROPERLY SECURE YOUR WIRING.



RELAY



PTO SWITCH

POSITION	CIRCUIT
OFF	C + G, B + H
ON	C + F, B + E, A + D

NON-REMOVABLE CONNECTIONS

REMOVABLE CONNECTIONS