



Mac Vac

Item	Part Number	Description
1.	82905-03-5	Cover •
2.	34004-99-4	Strain Relief Bushing •
3.	05001-99-5	Wire Nut •
4.	82901-02-6	Blower Housing—Upper•
5.	13450-96-0	Motor Assembly •
6.	15018-99-7	Screw •
7.	82902-00-8	Blower Housing—Lower•
8.	15060-99-9	Screw •
9.	82903-03-0	Nozzle •
10.	15060-99-9	Screw •
11.	32725-02-0	Axle•
12.	82919-00-2	Roller •
13.	82918-00-4	Spring •
14.	32726-00-2	Wheel Retainer•
15.	15018-99-7	Screw •
16.	82904-00-4	Carrier •
17.	82920-00-0	Spring for Kickstand •
18.	32725-03-8	Axle •
19.	82989-00-5	Wheel •
20.	32726-00-2	Wheel Retainer•
21.	82975-01-2	Gasket •
22.	82977-00-0	Bag Connector •
23.	82909-26-8	Bag •
24.	82908-00-5	Kickstand •
25.	09035-99-9	Screw •
26.	13001-99-5	Nut •
27.	00422-02-2	Wire Tie •
28.	82926-01-5	Handle—Lower•
29.	19001-99-9	Acorn Nut•
30.	64004-99-7	Carriage Bolt •
31.	82916-00-8	Handle—Upper •
32.	15031-99-0	Screw •
33.	82986-00-1	Grip Half—Left •
34.	12347-00-1	Pigtail—UK•
	12348-00-9	Pigtail—European •
	12349-00-7	Pigtail—Swiss •
	12350-00-5	Pigtail—Italy •
35.	12100-22-8	Switch •
36.	22288-00-5	RFI Filter •
37.	15104-99-5	Screw •
38.	00498-00-6	Cord Clamp •
39.	82985-00-3	Grip Half—Right •
40.	12226-00-7	Cord Protector •
41.	12346-00-3	2 Wire Power Cond