


REPAIR PARTS MANUAL MODEL NUMBER **PM105** (MFG. ID. NO. 96191001100) Snow Thrower



### **AUGER HOUSING / IMPELLER ASSEMBLY**




### **AUGER HOUSING / IMPELLER ASSEMBLY**

# SNOW THROWER - - MODEL NO. PM105 (96191001100) PRODUCT NO. 961 91 00-11

KEY NO.	PART NO.	DESCRIPTION	
4	532 19 10-79	Pulley, Impeller	
5	532 18 89-09	Bearing Assembly, Flange	
6	532 15 53-77	Nut, Hex Flange 5/16-18	
7	532 18 03-55	Bolt, Flat Head, Carriage 5/16-18 x 5/8	
8	872 27 05-05	Bolt, Carriage 5/16-1 8 x 5/8	
9	532 17 88-20	Nut, Cage 3/8-16	
10	532 18 45-17	Housing, Auger	
11	532 18 40-96	Bar, Scraper	
12	532 18 40-95	Bracket, Corner Discharge	
13 14	532 17 53-22 819 11 15-07	Base, Discharge Chute Washer, Flat	
15	810 04 05-00	Washer, Lock 5/16	
16	874 95 05-12	Screw, Hex Head 5/16-18 x 3/4	
18	532 17 95-82	Screw, Hex Head 5/16 x 1	
19	873 80 04-00	Nut, Hex Lock 1/4-20	
20	873 80 05-00	Nut, Hex Lock 5/16-18	
21	532 15 54-15	Washer, Flat 5/16	
22	532 18 40-94	Skid Plate, RH	
23	532 17 92-46	Washer, Nylon, Friction	
24	872 27 05-06	Bolt, Carriage 5/16-18 x 3/4	
25	532 18 56-00	Bolt, Shoulder 1/4-20	
26	532 17 46-58	Bearing, Auger	
27	532 17 46-97		
28	532 19 20-90		
29	532 18 40-93	·	
30 31	532 19 96-23 532 19 96-24		
32	532 17 46-99	O-Ring	
33	532 17 47-00	Bushing, Flange 3/4	
34	532 17 46-81	Washer, Thrust 3/4	
35	532 17 46-84	Bearing, Thrust 3/4	
36	532 17 46-60	9,	
37	532 17 46-83	· · · · · · · · · · · · · · · · · · ·	
38	532 17 46-86	Bushing, Flange 5/8	
39	532 15 00-78	Screw, Hex Head 5/16-18 x 3/4	
40	532 08 64-47	<b>0</b> ,	
41	532 17 46-88	· · · · · · · · · · · · · · · · · · ·	
42	532 17 46-98		
43	532 17 47-01	Bushing, Flange, 1"	
44	532 18 92-82	Key, Square 1/4 x 1/4 x 7/8	
45 46	532 17 46-59	Gear, Worm	
46 47	532 17 46-57 532 17 46-87	Shaft, Auger Housing, Gearbox, LH	
48	532 17 40-67	Impeller Assembly	
49	874 78 04-26	Screw, Hex Head 1/4-20 x 1-5/8	
50	532 17 53-11	Gasket, Gearbox	
51	532 18 42-05	Pin, Roll 3/16 x 1-1/8	
54	532 05 38-47		
	532 18 82-43	·	
	532 18 06-84	,	
57	532 <b>17 88-78</b>	Gearbox Assembly	

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm **IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your unit and void your warranty.


**CONTROL PANEL / DISCHARGE CHUTE** 



### **CONTROL PANEL / DISCHARGE CHUTE**

KEY NO.	PART NO.	DESCRIPTION
1	532 18 33-34	Knob, Lever
2		Screw #10-24 x 5/8
3	532 17 86-74	Control Assembly, Deflector
4	873 80 06-00	Nut, Lock 3/8-16
5	819 13 13-16	Washer, Flat 3/8
6	532 17 86-59	Control Assembly, Chute Rotater
7	532 18 40-89	Support, Pivot
8 9	532 15 00-78 532 18 45-05	Screw, Hex Head 5/16-18 x 3/4 Spring, Deflector
10	532 17 98-29	Bolt, Shoulder
11		Washer, Flat 1/4
	873 80 04-00	Nut, Lock 1/4-20
	872 25 05-05	Bolt, Carriage 5/16-18
14		Nut, Lock 5/16-18
15	532 18 45-10	Chute Assembly
16	532 18 45-11	Deflector Assembly
17	532 17 91-45	Seal, Deflector
18	532 12 84-15	Rivet, Blind
19	532 18 33-33	Knob, Speed Control Lever
20		Bolt, Carriage 5/16-18 x 3/4
22		Washer, Flat 5/16
24	874 78 05-28	Screw, Hex Head 5/16-18 x 1-3/4
25	532 15 53-77	Nut, Lock 5/16-18
26 27		Lever Assembly, Speed Control
27 28	532 16 96-75 532 18 04-45	Retainer, Hairpin
20 29		Rod, Upper, Speed Control Rod, Lower, Speed Control
30	532 19 27-10	Clamp, Clean-Out Tool
31	532 19 21-99	Tool, Clean-Out

REPAIR PARTS HANDLES



# REPAIR PARTS HANDLES

## SNOW THROWER - - MODEL NO. PM105 (96191001100) PRODUCT NO. 961 91 00-11


KEY NO.	PART NO.	DESCRIPTION
1	532 18 41-10	Lever, Auger Control, RH
2	532 18 41-09	Lever, Traction Drive Control, LH
3	532 17 94-39	Nut, Cage 1/4-20
4	532 17 88-88	Bushing, Flange
5	532 16 96-75	Retainer, Hairpin
6	532 18 04-02	Screw, Hex Head
7	532 17 86-52	Rod, Interlock
8	532 19 95-76	Arm, Impeller Rod
9	532 19 95-75	Arm, Traction Rod
10	532 19 95-31	Panel, Control
11	874 78 05-24	Screw, Hex Head 5/16-18 x 1-1/2
12	874 78 05-28	Screw, Hex Head 5/16-18 x 1-3/4
13	532 18 41-07	Handle Tube, LH
14	532 18 41-08	Handle Tube, RH
15	873 80 05-00	Nut, Lock 5/16-18
16	819 13 13-16	Washer, Flat 3/8
17	532 17 88-99	Knob, Handle
18	532 18 45-94	Rod, Auger Control
19	532 19 30-81	Rod, Traction Control
20	532 18 04-28	End, Control Rod
21	873 35 05-00	Nut, Hex, Jam 5/16-18
22	872 12 06-18	Bolt, Carriage 3/8-16 x 2-1/4
23	532 18 40-87	Handle Tube, Lower
24	532 18 04-47	Sleeve, Spring
25	532 18 09-26	Spring, Traction Drive
26	532 17 86-69	Spring, Auger Control
27	871 21 06-16	Screw, Hex Head 3/8-16 x 1
28	532 17 53-31	Bushing, Pivot Lever
30	532 18 29-06	Console, Panel
31	532 17 52-62	Screw, Hex Head, Tapping #10-24 x 1-1/4
32	532 18 44-71	Screw, Hex Head, Tapping #10-24 x 1/2
33	532 19 95-77	Latch, Interlock
34	532 18 35-18	Bolt, Shoulder
35	532 06 80-38	Nut, Lock 1/4-20
36	532 17 88-31	Spring, Interlegic
37	532 19 38-85	Spring, Interlock
38	532 17 86-66 <b>532 40 16-20</b>	Headlight, Halogen (Includes Bulb)
	532 40 16-20 532 17 86-68	Bulb, Halogen
39 40		Bezel, Headlight
40 41	532 18 09-64 532 17 88-90	Harness, Headlight (Halogen) Nut, Cage 3/8-16
42	532 17 86-90	Lever, Interlock
42 43	532 19 95-76	Rod, Latch, Interlock
43 44	532 19 63-38	Rod, Arm, Interlock
44 45	532 70 02-79	Clip
46	532 17 92-46	Washer, Friction
40	JUL 11 JL-40	vvasnon, i nouon

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm **IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your unit and void your warranty.

REPAIR PARTS


DRIVE

SNOW TUROWER MODEL NO. BM405 (00101001100) PROPUGENO. 001 01 00 11



KEY NO.	PART NO.	DESCRIPTION
1	532 14 63-15	Screw, Hex Head 5/16-18 x 3/4
2	873 80 05-00	Nut, Lock 5/16-18
3	532 15 54-15	Washer, Flat
4	817 49 05-08	Screw, Hex Head 5/16-18 x 1/2
5	532 18 00-17	Bearing, Flange
6 7	532 18 01-34 532 17 92-70	Shaft, Auxiliary Spacer, Plate
8	532 17 92-70	Plate, Auxiliary
9	532 18 00-82	Gear, Intermediate (12/58)
10	532 18 00-65	Gear, Pinion
11	532 18 77-14	Rod, Clutch
12	532 18 00-66	Shaft, Long, Hex
13	532 17 88-07	Pin, Pivot
14 15	532 18 40-80	Lever, Shifter / Wheel Trunnion Bearing Assembly
16	532 17 53-44 532 18 78-57	Bracket, Pivot, Shift
17	532 17 98-31	Ring, Rubber Wheel
18	532 19 95-09	Plate, Rubber Wheel
19	873 93 05-00	Nut, Lock 5/16-18
20	532 17 86-13	Hub, Rubber Wheel
21	874 76 05-14	Screw, Hex Head 5/16-18 x 7/8
22	532 08 51-79	Retainer, Hairpin
23 24	532 18 01-35 532 18 00-81	Spring, Bias Gear, Axle (58 Teeth)
25	532 17 86-95	Pin, Pivot Lever
26	532 19 77-63	Plate Assembly, Drive
27	532 17 93-52	Shaft, Axle
28	532 19 77-64	Shaft, Short Hex
29	532 18 40-77	Lever, Shifter Plate
30	532 18 40-76	Bracket, Shifter Support
31	872 27 05-05	Bolt, Carriage 5/16-18 x 5/8
32 33	532 18 92-82 532 18 89-09	Key, Square 1/4 x 1/4 x 7/8 Bearing, Flange
34	532 18 40-75	Plate, Drive Mounting
35	532 18 25-04	Spacer, Bearing
36	532 19 10-80	Pulley, Traction Drive
37	532 15 53-77	Nut, Lock 5/16-18
38	819 11 15-07	Washer, Flat
39	810 04 05-00	Washer, Lock 5/16
40 41	874 95 05-12 812 00 00-12	Screw, Hex Head 5/16-18 x 3/4
41 42	812 00 00-12	Ring, Retaining Washer, Lock, External Tooth 5/16
43	532 17 90-95	Spring, Return
44	532 18 42-06	Pin, Roll
		•


SNOW THROWER - - MODEL NO. PM105 (96191001100) PRODUCT NO. 961 91 00-11




#### **CHASSIS / ENGINE / PULLEYS**

KEY	PART		KEY	PART	
NO.	NO.	DESCRIPTION	NO.	NO.	DESCRIPTION
1	532 18 10-44	Spring, Traction Idler	29	532 19 22-13	Belt Cover Assembly
2		Pulley, Idler (2-1/4)			(Includes Toolbox Cover)
3		Engine, Tecumseh,	30	532 17 88-30	Cover, Toolbox
		Model Number OH318SA (Order	31	817 49 04-08	Screw, Hex Head 1/4-20 x 1/2
		parts from Engine manufacturer)	32	532 17 92-56	Bolt, Shoulder 5/16-18
4	874 78 05-20	Screw, Hex Head 5/16-18 x 1-1/4	33	532 18 78-53	Bellcrank Shifter
6	532 05 92-89	Washer, Flat	34	532 18 04-01	Screw, Hex Head 1/4-28 x 3/4
7	873 93 05-00	Nut, Jam, Lock 5/16-18	35	532 19 57-67	Arm, Auger Control
8	532 17 53-30	Pin, Idler Pivot	36	873 80 05-00	Nut, Lock 5/16-18
9	532 17 90-92	V-Belt, Traction Drive	37	532 18 40-86	Bellcrank
10	810 04 05-00	Washer, Lock 5/16	38	532 18 17-01	Link, Speed Control
11	817 49 05-08	Screw, Hex Head 5/16-18 x 1/2	39	532 19 21-10	Trunnion, Pivot Bracket
12	532 17 92-59	Impeller Arm / Pad Assembly	40	532 17 88-20	Nut, Cage
13	532 08 51-79	Retainer, Hairpin	41	532 70 02-79	Hairpin, Cotter 3/32 x 1/2
14	532 17 88-28	Spring, Brake	42		Pin, Pivot Bracket
15	532 18 35-33	V-Belt, Impeller Drive	43	532 18 40-85	Bracket, Bellcrank
16	532 19 23-06	Screw, Hex Head 3/8-16 x 1-1/4	44	871 21 06-16	Screw, Hex Head
17	532 18 40-74	Arm, Idler	45	532 18 40-74	Bracket, Impeller Idler Arm
18	874 78 05-24	Screw, Hex Head 5/16-18 x 1-1/2	46	532 18 45-10	Pan, Frame Bottom
19	532 17 53-31	Bushing, Idler Pivot	47	871 02 05-12	Screw, Hex Head 5/16-18 x 3/4
20	532 18 05-23	Pulley, Idler (2-3/4)	48	532 18 11-56	Nut, Speed 5/16-18
21	874 61 05-16	Screw, Hex Head 5/16-18 x 1	49	532 18 45-07	Frame Assembly
22	532 17 93-71	Spacer, Engine Pulley	50	532 18 83-69	Plate, Frame End
23	532 18 04-78	Pulley, Engine, Traction Drive	51	532 19 95-14	Shaft, Auger Control
24	532 17 91-57	Pulley, Engine, Impeller Drive	52	532 05 70-79	Washer, Hardened
25	532 06 27-35	Washer, Flat 3/8	53	532 19 22-75	Roller
26	532 85 02-63	Washer, Lock 3/8	54	532 19 21-47	Ring, Crescent
27	532 85 10-84	Screw, Hex Head 3/8-24 x 1-3/8	55	812 00 00-02	E-Ring
28	532 15 54-52	Guide, Belt	57	811 05 05-00	Washer, Lock, External Tooth 5/16

REPAIR PARTS WHEELS / DECALS





#### WHEELS / DECALS

	PART NO.	DESCRIPTION
1	532 18 79-04	Wheel Assembly, 16", LH
2	532 15 54-43	Pin, Klik 1/4
3	532 18 79-05	Wheel Assembly, 16", RH
4	532 14 63-15	Screw, Hex Head 5/16-18 x 5/8
5	532 17 98-30	Bearing, Axle
6	532 17 46-97	Washer, Thrust, 1"

KEY NO.	PART NO.	DESCRIPTION
1	532 18 40-26	Decal, Danger
2	532 18 77-32	Decal, McCulloch, 76cm
3	532 18 40-27	Decal, Danger, Deflector
4	532 18 40-45	Decal, Danger
5	532 18 77-29	Decal, McCulloch
6	532 18 40-30	Decal, Instruction
7	532 18 40-36	Decal, Traction Lever
8	532 18 40-35	Decal, Auger Lever
9	532 18 40-32	Decal, Speed Control
10	532 18 40-31	Decal, Remote Deflector
13	532 18 41-24	Decal, Height Adjustment
14	532 18 04-33	Decal, Sound Level
15	532 18 40-28	Decal, Belt Guard
16	532 18 40-37	Decal, Fuel Shut-Off
	532 19 95-86	Operator's Manual, European
	532 19 95-87	Operator's Manual, Scandinavian
	532 19 95-85	Operator's Manual, East Bloc
	532 19 95-93	Repair Parts Manual, English

## **SERVICE NOTES**

## **SERVICE NOTES**

### LIMITED WARRANTY

The Manufacturer warrants to the original consumer purchaser that this product as manufactured is free from defects in materials and workmanship. For a period of two (2) years from date of purchase by the original consumer purchaser, we will repair or replace, at our option, without charge for parts or labor incurred in replacing parts, any part which we find to be defective due to materials or workmanship. This Warranty is subject to the following limitations and exclusions:

- This warranty does not apply to the engine. Please contact your nearest dealer where they will send the machine to the engine manufacturer.
- Transportation charges for the movement of any power equipment unit or attachment are the responsibility of the purchaser. Transportation charges for any parts submitted for replacement under this warranty must be paid by the purchaser unless such return is requested by your dealer.
- 3. Battery Warranty: On products equipped with a Battery, we will replace, without charge to you, any battery which we find to be defective in manufacture, during the first ninety (90) days of ownership. After ninety (90) days, we will exchange the Battery, charging you 1/12 of the price of a new Battery for each full month from the date of the original sale. Battery must be maintained in accordance with the instructions furnished.
- The Warranty period for any products used for rental or commercial purposes is limited to 90 days from the date of original purchase.
- 5. This Warranty applies only to products which have been properly assembled, adjusted, operated, and maintained in accordance with the instructions furnished. This Warranty does not apply to any product which has been subjected to alteration, misuse, abuse, improper assembly or installation, delivery damage, or to normal wear of the product.
- 6. Exclusions: Excluded from this Warranty are belts, normal wear, normal adjustments, standard hardware and normal maintenance.
- 7. In case of any problem within the boundaries of this warranty, contact the nearest department store, indicate the model number, serial number and the date of purchase of your machine. This warranty does not apply to accidental damages. All implicit warranties are limited to the same time frames. Or contact:

E.M. Services 54 Rue Lambrechts 92400 Courbevoie France Telephone: (1) 46678078

Fax: (1) 46678095

THIS WARRANTY DOES NOT APPLY TO INCIDENTAL OR CONSEQUENTIAL DAMAGES. ANY IMPLIED WARRANTIES ARE LIMITED TO THE SAME TIME PERIODS STATED HEREIN.

