

# 5110 XQT 5110 XST

Pag 1 di 2

COD.	MOD.	*	□	⊗	✦	☆	**	△	⊙	
S06301	5110 XST	110116214	150091910	150091810	200101100(2)	200090010(2)	200013600(2)	200090010(2)	090054700(8)	
S06303	5110 XST	110116219	150091910	150091810	200101100(2)	200090010(2)	200013600(2)	200090010(2)	090054700(8)	
S06305	5110 XST	110116223	150091910	150091810	200101100(2)	200090010(2)	200013600(2)	200090010(2)	090054700(8)	
S06306	5110 XST	110116214	150091910	150091810	200101100(2)	200090010(2)	200013600(2)	200090010(2)	090054700(8)	
S06307	5110 XQT	110116214	150091910	150091810	200101100(2)	200090010(2)	200013600(2)	200090010(2)	090054700(8)	
S06308	5110 XST	110116214	150091910	150091810	200101100(2)	200090010(2)	200013600(2)	200090010(2)	090054700(8)	
S06309	5110 XQT	110116231	150091910	150091810	200101100(2)	200090010(2)	200013600(2)	200090010(2)	090054700(8)	
S06312	5110 XST	110116223	150091910	—————	200101100(2)	200090010(2)	200013600(2)	200090010(2)	090054700(8)	
S06313	5110 XQT	110116223	150091910	—————	200101100(2)	200090010(2)	200013600(2)	200090010(2)	090054700(8)	



