

Stand 12.02.2001


ERSATZTEILLISTE

Motorsäge CST-600EVL

ECHO-Motorgeräte
Vertrieb Deutschland GmbH
Otto-Schott-Str. 7

72555 Metzingen

Telefon 07123-1091
Telefax 07123-2589
<http://www.echo-shop.de>
email: info@echo-shop.de



Key No.	Part No.	Q'ty	Description	Key No.	Part No.	Q'ty	Description
1	900 100-0501 6	2	Bolt 5 x 16	1- 67	900 720-0000 6	1	O-ring 6
2	900 603-0000 5	4	Washer 5	68	130 111-0053 0	1	Clip
3	177 218-0283 0	2	Ratchet	69	437 210-1113 0	1	Oil pipe
4	177 217-0343 0	2	Spacer	71	436 205-1473 0	1	Oil strainer
5	177 234-0283 1	2	Spring, ratchet	72	900 105-0501 0	2	H.S.H. bolt 5 x 10
6	100 144-0283 0	1	Nut	76	433 028-1103 0	1	Clip
7	100 143-1613 0	1	Lock washer	77	433 016-1103 1	1	Adjusting screw
10	150 626-1613 0	2	Ignition coil	78	433 014-0283 0	1	Tensioner
11	900 162-0401 8	6	H.S.H. bolt 4 x 18	79	900 162-0501 4	2	H.S.H. bolt 5 x 14
12	150 611-1613 0	2	Tube	80	880 210-1433 0	1	Spike
13	150 112-0031 0	2	Grommet	81	900 500-0000 5	2	Nut 5
14	150 601-1613 0	1	C.D. Ignition module	82	433 011-1233 0	2	Stud
15	150 800-1613 0	1	Roter	83	100 251-1613 0	1	Side cushion (F)
18	150 614-0291 0	1	Grommet	84	100 252-1613 0	1	Side cushion (R)
21	900 162-0503 5	4	H.S.H. bolt 5 x 35	85	437 000-0343 0	1	Auto, oiler ass'y
22	100 212-1613 0	1	Oil seal	86	-437 020-0283 0	3	O-ring
23	100 200-1603 0	1	Crankcase set	87	-437 019-0283 0	1	Coil spring
20	-100 215-0393 0	4	Knock	88	436 001-1613 0	1	Cap ass'y, oil tank
28	-100 215-0573 1	2	Knock	89	-900 720-0002 5	1	O-ring 25
24	900 810-3620 2	2	Ball bearing 6202	90	175 310-1613 0	1	Seal plate
25	100 100-1613 0	1	Crank shaft ass'y	91	900 242-0401 0	15	Screw 4 x 10
26	900 702-0003 5	1	Circuit 35	*	175 000-1233 0	1	Clutch ass'y
27	100 273-1613 0	1	Gasket, crankcase (L)	92	-175 016-0343 0	1	Boss, clutch
29	100 213-0283 0	1	Oil seal	93	-175 018-0283 0	1	Spring, clutch
30	100 142-1233 0	1	Woodruff key	94	-175 017-0283 0	3	Shoe, clutch
31	100 281-1613 0	1	Gasket, crankcase (U)	95	175 005-1103 0	1	Clutch case 3/8
33	100 012-0072 0	2	Needle bearing	96	100 012-1233 0	1	Needle bearing
34	100 010-1613 0	2	Piston	97	175 015-0343 0	1	Washer
35	100 013-1613 0	2	Piston pin	98	100 129-0343 0	1	Lock nut (L)
36	100 015-0393 0	4	Circlip	**	433 100-1613 0	1	Chain brake ass'y
37	100 011-1613 0	4	Piston ring	91	-900 242-0401 0	3	Screw 4 x 10
38	101 010-1613 0	2	Gasket, cylinder	100	-433 113-1233 0	1	Pivot
39	101 711-1613 0	1	Cylinder, front	101	-433 105-1613 0	1	Brake handle
40	900 162-0502 0	8	H.S.H. bolt 5 x 20	102	-433 312-1233 0	1	Cover
41	101 514-1613 0	1	Cover, cylinder (F)	103	-433 149-1613 0	1	Reset, brake
43	159 015-1613 0	1	Cap, cylinder cover	104	-433 313-1233 0	1	Dust seal
44	159 010-1063 0	2	Spark plug BPM7A	105	-433 117-1233 0	1	Connector
45	159 011-0343 2	2	Coil spring	106	-433 115-1233 0	1	Spacer
46	159 012-0343 3	2	Cap, spark plug	107	-433 119-1233 0	1	Stopper
47	101 743-1613 1	1	Cylinder, rear	108	-433 114-1233 0	1	Spring
48	101 576-1613 0	1	Cover, cylinder (R)	109	-433 134-1233 0	1	Bolt
51	145 510-1613 0	1	Gasket, muffler	110	-433 123-1233 0	1	Brake band
52	145 605-1613 0	1	Muffler	111	-433 144-1233 0	1	Retainer
53	130 031-1023 0	4	Washer	112	-900 242-0501 0	2	Screw 5 x 10
54	900 105-0503 8	4	H.S.H. bolt 5 x 38	113	-433 142-1233 0	1	Adjuster
56	145 862-1613 0	1	Screen	114	-433 310-1613 0	1	Cover
57	145 863-1613 0	1	Screen holder	117	433 013-1613 0	1	Side plate
58	900 610-0000 5	6	Lock washer 5	119	430 212-1613 0	1	Guide bar 50RS50-3/8E
59	145 643-0373 0	6	Screw 5 x 8	120	431 012-1193 0	1	Chain 72DP-72E
60	145 866-1613 0	1	Gasket	121	433 012-1613 0	1	Side plate
61	145 861-1613 0	1	Lid, muffler	122	433 010-1613 0	1	Cover, guide bar
62	101 534-1613 0	1	Plate	123	433 019-1233 0	2	Flange nut
64	900 241-0300 8	1	Screw 3 x 8	124	890 021-0393 1	1	Decal, ECHO
65	437 306-1603 0	1	Connector	125	433 031-1613 0	1	Isolater
66	900 720-0000 7	1	O-ring 7				

Remarks:


23 Includes 20 and 28.

85 Includes 86 and 87.

88 Includes 89.

* Consists of 92 thru 94.

** Consists of 91 and 100 thru 114.



	Part No.	Q'ty	Description	Key No.	Part No.	Q'ty	Description
1	890 151-1613 0	1	Decal	2- 61	900 162-0502 0	3	H.S.H. bolt 5 x 20
3	130 302-1613 0	1	Cover ass'y, air cleaner	62	351 142-1613 0	1	Lid, supporter
2	.130 415-1613 0	1	Thumb bolt	63	351 144-1613 0	1	Bracket
4	130 428-1473 0	2	Nut	64	351 145-1613 0	1	Cover, bracket
5	130 310-1613 0	1	Air filter (U)	65	100 253-1613 0	1	Cushion
6	130 317-1613 0	1	Air filter (L)	66	351 614-1613 0	1	Supporter
7	129 030-1613 0	1	Foam pad	67	351 617-1023 0	1	Insert
8	130 712-1613 0	2	Stud	68	351 606-1613 0	1	Front handle
9	130 711-1613 0	1	Elbow, carb	69	900 106-0501 4	2	H.S.H. bolt 5 x 14
10	900 162-0505 5	2	H.S.H. bolt 5 x 55	76	900 242-0400 8	2	Screw 4 x 8
11	123 000-1613 0	1	Carburetor HDA	77	177 262-1613 0	1	Side plate
12	130 521-1613 0	1	Gasket	**	177 200-1613 0	1	Recoil starter ass'y
13	130 320-1613 0	1	Foam gasket	36	-900 242-0401 0	2	Screw 4 x 10
14	130 505-1613 0	1	Adapter	79	-900 242-0501 0	1	Screw 5 x 10
15	900 244-0501 8	4	Screw 5 x 18	80	-177 214-0283 0	1	Washer
16	130 614-1613 0	1	Gasket	81	-177 243-0283 3	1	Pawl catcher
17	130 600-1613 0.	1	Reed valve ass'y	82	-177 246-0283 2	1	Clip
18	130 610-1613 0	1	Gasket	83	-177 215-0283 4	1	Recoil drum
22	900 220-0506 5	1	Screw 5 x 65	84	-177 216-0283 2	1	Bush
23	890 022-0343 0	1	Decal, oil adjust	85	-177 242-1233 0	1	Side plate
24	437 039-1613 0	1	Dial	86	-177 220-0283 4	1	Rewind spring
25	437 614-1613 0	1	Grommet, dial	87	-177 221-0283 0	1	Side plate
*	131 600-1023 1	1	Cap ass'y, fuel tank	88	-177 226-0283 0	1	Starter rope
26	-890 154-1273 0	1	Decal	89	-177 229-1433 0	1	Spacer
27	-131 017-1023 1	1	Cap	90	-177 228-1233 0	1	Handle, starter
28	-131 314-0033 0	1	Check valve	91	-177 227-0502 0	1	Rope guide
29	-131 015-0083 0	1	Holder, valve	92	-177 209-1613 0	1	Case, starter
30	-900 720-0002 9	1	O-ring 29	93	890 112-1233 0	1	Decal, ECHO
31	900 105-0501 0	2	H.S.H. bolt 5 x 10	94	900 700-0000 4	1	Circlip 4
34	900 720-0000 7	1	O-ring 7	95	437 056-0283 0	1	O-ring
35	132 011-1613 0	1	Connector	96	129 020-1613 0	1	Coil spring
36	900 242-0401 0	6	Screw 4 x 10	97	129 013-1613 0	1	Adjuster, idle
37	132 012-1613 0	1	Fuel pipe (O)	100	895 610-0013 0	1	L-wrench, 4
38	132 010-1613 0	1	Fuel pip (I)	101	895 812-0393 0	1	Screw driver
39	900 603-0000 5	1	Washer 5	102	895 410-0283 0	1	Wrench w/s, driver
40	131 200-0283 0	1	Fuel strainer	115	437 240-1603 0	1	Connector
41	163 400-1613 0	1	Switch	116	437 206-1603 0	1	Oil pipe
42	100 905-1613 0	8	Cushion	120	437 228-1603 0	1	Oil pipe
43	178 211-0033 0	1	Grommet	***	437 100-1603 0	1	Pump ass'y
44	178 510-1613 0	1	Choke rod	117	-437 052-0033 0	1	Connector
45	351 905-1613 0	1	Rear handle	118	-437 013-0033 0	2	Valve spring
46	129 010-1233 0	1	Grommet	119	-437 012-0033 0	2	Ball valve
47	150 614-0291 0	1	Grommet	121	-437 017-0033 0	1	Connector
48	178 302-1233 0	1	Throttle latch	121	-131 310-0023 0	1	Gasket
49	900 340-5002 5	1	Spring pin 5 x 25	123	-437 111-1603 0	1	Pump spring
50	900 340-4001 3	2	Spring pin 4 x 13	124	-900 720-0000 5	1	O-ring
51	351 111-1613 0	1	Grip	126	-437 101-1603 0	1	Pump piston
52	178 011-1613 0	1	Throttle rod	127	-437 119-1603 0	1	Push botton
53	178 010-1233 1	1	Throttle				
54	178 090-1233 0	1	Throttle control lockout				
55	178 091-1053 1	1	Spring				
57	900 162-0501 4	7	H.S.H. bolt 5 x 14				
58	900 162-0503 0	2	H.S.H. bolt 5 x 30				
59	351 123-1613 0	1	Supporter				
60	900 162-0501 8	10	H.S.H. bolt 5 x 18				


Remarks:

3 Includes 2.

* Consists of 26 thru 30.

** Consists of 36 and 79 thru 92.

*** Consists of 117 thru 127 except 120.



Key No.	Part No.	Q'ty	Description
3- *	123 000-1613 0	1	Carburetor ass'y HDA 7
1	-123 144-0393 0	4	Screw
2	-123 142-1613 0	1	Cover, m. diaphragm
3	-123 141-1613 0	1	Diaphragm, metering
4	-123 140-1613 0	1	Gasket, m. diaphragm
5	-123 114-0393 0	3	Screw
6	-123 116-1613 0	1	Valve, throttle
7	-123 117-1613 0	1	Shaft, throttle
8	-123 113-1613 0	1	Spring, t. return
9	-123 139-0393 0	1	Screw, m. lever pin
10	-123 138-0393 0	1	Pin, m. lever
11	-123 123-1613 0	1	Lever, metering
12	-123 137-1613 0	1	Valve, inlet
13	-123 122-1613 1	1	Spring, m. lever
15	-123 169-1063 0	1	Ring, screen
16	-123 168-1063 1	1	Screen, check valve
19	-123 121-1613 0	2	Spring, needle
21	-123 120-1613 1	1	Needle, high
22	-123 118-1613 0	1	Needle, idle
23	-123 133-1113 0	1	Spring, idle adjust
24	-123 134-1613 0	1	Screw, idle adjust
25	-123 156-1233 0	1	Stop, throttle
26	-123 132-1613 0	1	Valve, choke
27	-123 131-1613 0	1	Shaft, choke
28	-123 136-1063 0	1	Ball, choke friction
29	-123 135-1063 0	1	Spring, choke friction
30	-123 126-1063 1	1	Screen, inlet
31	-123 112-1233 0	1	Diaphragm, pump
32	-123 131-1613 0	1	Gasket, pump
33	-123 124-1613 0	1	Cover, pump
34	-123 110-1613 0	1	Screw, pump cover
35	-123 167-1233 0	2	Screw
36	-123 166-1613 0	1	Plate, circuit
37	-123 164-1613 0	1	Gasket, circuit plate

Remark:

* Consists of 1 thru 37.



ECHO®

Motorgeräte

die geh'n ran